

Grid Code List

- The list includes grid codes in Sunways Inverter STH3-8KTL-HS/HSS.
- The grid codes are subject to change. The listed codes are for reference only.
- G98 grid code is only available for STH-3KTL-HS, STH-3KTL-HSS, STH-3.6KTL-HS, STH-3.6KTL-HSS.
- G99 grid code is only available for STH-4.2KTL-HS, STH-4.6KTL-HS, STH-5KTL-HS, STH-6KTL-HS, STH-7KTL-HS, STH-8KTL-HS.
- Belgium grid code is only available for STH-3KTL-HS, STH-3.6KTL-HS, STH-4.2KTL-HS, STH-4.6KTL-HS, STH-5KTL-HS.

	Grid code	Country	Remark
1	50Hz Default	Reserved	
2	60Hz Default	Reserved	
3	VDE4105	Germany power grid	
4	ES:TED749	Spain power grid	
5	Spain NTS-A	Spain power grid	Available only in Sunways inverter delivered to Spain. Contact us if you need.
6	EN50549	Europe low-voltage (LV) power grid	
7	Vietnam	Vietnam power grid	
8	IEC61727 (50Hz)	IEC61727 power grid (50Hz)	
9	IEC61727 (60Hz)	IEC61727 power grid (60Hz)	
10	India	India power grid	
11	Philippines	Philippines power grid	
12	Sri Lanka	Sri Lanka power grid	
13	Italy	Italy low voltage (LV) power grid	
14	EN50549 (CZ)	Czech power grid	
15	EN50549 (TR)	Turkey power grid	
16	EN50549 (IE)	Ireland power grid	
17	EN50549 (SE)	Sweden power grid	
18	EN50549 (HR)	Hungary power grid	
19	Belgium	Belgium power grid	
20	South Africa	South Africa power grid	
21	G98	UK G98 power grid	
22	G99	UK G99 Type_A_LV power grid	